



Beagle Sur
Departamentos

SMART LIFE :: TOSTADORA DE SANDWICHS

- › Conectar el cable a un tomacorrientes, se encenderá la Luz roja
- › Preparar 1 ó 2 Sándwiches MIENTRAS SE CALIENTA la TOSTADORA
- › Colocar los Sándwiches ya preparados en la TOSTADORA
- › Se encenderá la luz verde, demora aproximadamente 5 minutos la cocción
- › Abrir y revisar si está a gusto del consumidor, si precisa más calor, volver a cerrar y se encenderá la luz verde nuevamente hasta que se apague.
- › Retirar los Sándwiches Tostados con una espátula para evitar quemaduras
- › Limpiar con un paño húmedo cuando esté frío

NO SE RECOMIENDA HACER SANDWICHS MUY GRUESOS NI COCINAR MAS DE UNA VEZ



Beagle Sur
Departamentos

SMART LIFE :: SANDWICH TOASTER

- › Connect the cable to a power outlet, the red light will turn on
- › Prepare 1 or 2 Sandwiches WHILE THE TOASTER IS HEATING
- › Place the already prepared Sandwiches in the TOASTER
- › The green light will turn on, it takes approximately 5 minutes to cook.
- › Open and check if it is to the consumer's liking, if more heat is needed, close again and the green light will turn on again until it goes off.
- › Remove the Toasted Sandwiches with a spatula to avoid burns.
- › Clean with a damp cloth when cold

IT IS NOT RECOMMENDED TO MAKE VERY THICK SANDWICHES OR COOK MORE THAN ONCE.